MC 521 YELLOW LABEL SETUP FOR DURA GLIDE SLIDING PACKAGE

Power **ON**

Turn Mode selector switch to **CLOSED** or **OFF**

Remember when releasing enter you only have 2 seconds to make a change

A) Hold enter and press down to **#99**
Release enter, press down one time to **#00**

B) Hold enter and press down to **#96**
Release enter, press up one time to **#01**
You will then see "A0" on display

C) Hold enter and press up to **#00**
Release enter, press up to until you see **#01**(single motor) or **#02**(dual motor)
You will then see "AO" on display

D) Hold enter and press up to **#01**
Release enter, go to **"00"** for right hand(CCW*) or **"01"** for left hand(CW**)
*when manually opening door, pulley on gearbox spins **Counter Clockwise**
when manually opening door, pulley on gearbox spins **Clockwise
You will then see "A0" on display

E) Hold enter and press up to **#03**
Release enter, press **UP** one time
You will see "20" briefly, then "A1" on display

F) Hold enter and press up to **#11**
Release enter, go to **"00"** for **Rotary** switch logic, or **"01"** for **Rocker** switch logic
You will see "A1" on display

G) If you have an **Electric lock** you will do this next step(H), if **NO electric lock** is present, please skip (H).

H) Hold enter and press up to **#07**
Release enter, change to **"00"** for **Fail Safe** lock, or **"01"** for **Fail Secure** lock.

I) With the door in the fully closed position, you will now flip your mode switch to **HOLD OPEN. AS SOON AS THE DOOR BEGINS TO MOVE, FLIP THE MODE SWITCH BACK TO CLOSED/OFF**. The door will now go thru a "learn" process. This consists of the door opening and closing several times until you see "**A2**" on the display. Once "**A2**" is present you will:

J) Hold enter and press down to **#99**
Release enter, press up one time to **"01"**
It will then read "20" briefly, then go to **"00"**

At this point you may put your switch to **AUTOMATIC** and run your door.

AUTOMATIC DOOR AND HARDWARE